

SHOWER SEAT ASSEMBLY INSTALLATION

Shower seat assembly "Leg Panels" set on shower base threshold. Using 100% Silicone Adhesive (or any good wall adhesive), set the "Leg Panels" of the shower seat assembly, one at a time, into the corner of the shower.

1

Panels should sit ON TOP OF THE THRESHOLD and AGAINST THE WALL PANELS.

2

Silicone the seat to the top of the "Leg Panels" and against the Wall Panels of the shower.

