

TRIM TABS

**Wall out of square?
Vanity top doesn't fit?**

US Marble's "Trim Tabs" are the answer.

The tab (indicated by a star) at the top of the backsplash, or on the front edge of the top, can be simply filed off using a flat file. This creates an 'out of square top' to match your wall and, once the gap is covered with a side splash, no one will know.



You must add 1/4" to required length to allow for removal of tabs where necessary. In the example drawn below, the left wall was angled out, so by filing off the back tab, and allowing top to slide left, when a splash is added, you have the perfect professional installation you wanted.

Note:

- Requires a side splash.
- If your back wall measurement, and front edge measurement are more than 1/2" different, this will NOT correct the problem.

