

SHOWER SEAT ASSEMBLY INSTALLATION INSTRUCTIONS

1. Shower seat assembly “Support Panels” set on the shower base threshold. Using 100% Silicone Adhesive (or any good wall adhesive), set the “Support Panels” of the shower seat assembly, one at a time, into the corner of the shower. Panels should sit ON TOP OF THE THRESHOLD and AGAINST THE WALL PANELS.

2. Silicone the seat to the top of the “Support Panels” and against the Wall Panels of the shower.

