

UNIVERSAL ACCESS RAMP SHOWER THRESHOLD INSTALLATION INSTRUCTIONS

1. Place the access ramp against the shower base.
2. Where the ramp meets the edge of the shower base, the ramp may be lower than the shower base. If this is the case, place Thin Set or Quick Set mortar on the ground to adjust the height of the access ramp to be even with or $\frac{1}{4}$ " above the height of the shower base.

Note: The mud below the access ramp will work better than wooden shims because it supports the entire access ramp, preventing it from cracking or breaking when a wheelchair rolls over it.

3. Use a level to make sure the access ramp is placed correctly against the shower base.
4. The seam between the base and the ramp needs to be sealed with silicone.
5. Let the mortar dry, and the access ramp is ready to be used.

